

BROMINE **HOT TUB SUPPLIES KIT**







Bromine 4-in-1 Test Strips:

Tests water Total Bromine, Total Alkalinity (TA), pH, and Hardness. Fill the spa with fresh water, then test for TA, pH, and Hardness. Note results. Bromine is tested later.





Alkalinity Up:

Increases low Total Alkalinity (TA) and buffers pH. If TA tests below 80-120 ppm range, add in 1 oz. (2 tablespoon) increments. Circulate water 30 minutes, retest.







Lowers high pH and TA. If pH tests above 7.6, add in 1 oz. (2 tablespoon) increments. Pre-dissolving recommended. Circulate water 30 minutes, then retest.





Increases low Hardness. If tests below 150-300 ppm range, add in 1 oz. (2 tablespoon) increments. Pre-dissolving recommended. Circulate water 30 minutes, then retest.



Bromine Tablets:

Slow-dissolving spa water sanitizer. For use in Floating Tablet Dispenser. Bromine level will be tested later with Bromine 4-in-1 Test Strips.



Floating Bromine Tablet Dispenser:

Load with bromine tablets. Set release rate per directions. Place in spa. Test sanitizer level after 24 hours. Adjust to maintain 3 to 5 ppm bromine. Retest periodically.



Bromine Booster:

Establishes an immediate bromide reserve at startup, before Bromine Tablets have had time to dissolve. Add 1/2 oz. per 100 gallons when spa is initially filled.



Oxy-Spa Non-Chlorine Shock:

Helps to maintain water quality. Add 1 tablespoon per 250 gallons at startup and weekly or after each use.





Metal Free:

Prevents staining and corrosion from dissolved metals. Add about 1/2 bottle per 300 gallons on startup and with each water change, per label directions.



Chitosan Clarifier:

Promotes crystal clear water naturally. Add 1 oz. at startup and weekly per 300-500 gallons.



Rev. 05-20-20



ZorbO Oil Scum Absorber:

Hi-tech polymer with flow-thru design wicks-up oily film and inanimate scum. Float in hot tub. Replace every 3 to 4 months.

(800) 823-3638 | Mon-Fri 6 AM-5 PM Pacific

